




Universal Welded Wire Pen Assembly Instructions



Shown with optional Dog House.


Important Notes:

Lay out all components prior to start of assembly.

Flat level surface recommended for assembly.

If any components are missing or damaged do not return to retailer. Please call Rugged Ranch Products at: 760-734-3748


Please visit our website to see our complete line of Rugged Ranch Products.
www.ruggedranch.net



Dog House



Wooden Chicken Hutch




Don't forget to complete your Universal Welded Wire Pen by adding the optional Wooden Chicken Hutch or Dog House!

Dog House and Chicken Hutch are attached outside pen via knock-out back panel to save room inside pen.

Step 1


Lay out all panels as shown. Assemble Gate Panel (B) on the outside of Side Panel (C).

**Panels A, B, and D must be attached on the outsides of Side Panels (C) in order for the Roof Panels (E) to fit properly.




Step 2

Connect each panel to one another as shown using (2) Clamps (G) per panel. In this process you will use (16) Clamps (G).
*Red boxes indicate approximate clamp placement.



Step 3


Using (2) Roof Connectors, connect (2) Roof Panels (E) together. Do the same with last two Roof Panels.



Step 4

Place Roof Panels (E) on top of base of coop and connect using the remaining (16) Clamps (G). Tighten all loose bolts and assembly is complete.

*Red boxes indicate approximate clamp placement. When connecting Side Panel (C) to Roof Panel (E), clamps will connect in the vertical position NOT at an angle.



**It is important to note that some panels of this metal coop have extra cutouts to place more clamps. It is not required to use a clamp in each opening, only in approximate positions demonstrated in diagram.